

Front Plywood

front and back angle:

1' 3 5/8" x 24", 7 13/16" x 12"

150 3' 6 3/8"
151 3' 6 3/8"
152 2' 11"
153 2' 10 15/16"
154 6' 1 7/16"
155 6' 2 1/16"
156 4' 7 1/4"
157 4' 5 3/8"
158 5' 11 3/4"
159 4' 10 1/4"
160 6' 10 3/16"
161 3' 6 3/8"
162 2' 8 5/8"
163 5' 5 7/8"
164 6' 10 1/4"
165 3' 6 3/8"

Front Bevel Cut

-101a 7' 10 11/16":Adjusted to fit window
-101b 7' 9 5/8"
-102 6' 11 1/4"
-103 6' 7/8"
-104 5' 2 7/16"
-105 4' 4"
-106 3' 5 5/8"
-107 2' 7 3/16"
-108 1' 8 3/4"
-109 10 3/8"

-119a 7' 11 5/8":Adjusted to fit window
-119b 7' 10 9/16"

- 120 4' 4 9/16":double top bevel
- 121 2' 7 13/16":double top bevel

- 119c 6 7/16":Adjust to fit window
- 128 1' 2 7/8":Adjust to fit window
- 129 1' 2":Adjust to fit window
- 101c 5 1/2":Adjust to fit window

-----Different Angle, not all front bevel-----

- 122 7' 5 1/16":Top angle: Front bevel
Bottom angle: 3"x 1 5/16"
- 134 5' 6 7/8":double bottom bevel,
Top angle: 3"x 1 5/16"
Bottom angle: Front bevel

Front Square Cut

- 110 4' 6 1/4"
- 111 6' 4 3/8"
- 112 5' 5 13/16"
- 113 not used
- 114 11' 3 3/8"
- 115 not used
- 116 6' 3"
- 117 8' 10 1/8"
- 118 8' 8 1/4"
- 135 10' 1 1/8"

- 124 3' 1/8"
- 125 (6' 10 11/16"):double 2x4
- 126 (6' 10 11/16"):double 2x4
- 127 3' 6 3/8":Adjust to fit window
- 130 3' 3 15/16":Adjust to fit window
- 131 3' 3 15/16":Adjust to fit window

-123 (3' 6 3/8"):frontHeader, Adjust to fit

-132 11' 8 5/8":frontAtticSpacer

Front Right Side Support

--133ab 2' 1 1/8" square cut

133c 3 1/2" x 11" x 1' 1 3/16" x 1 3/4"
diagonal cut

Door Cover

136a 5 1/2" x 6' 9 13/16" Top plate, left

136b 5 1/2" x 15' 7 3/4" Top plate, right

-137(2) 9 1/4" x 8' second floor joist

-138(8) 9 1/4" x 10' second floor joist

139(1) 9 1/4" x 4' 1" second floor joist

140(1) 3 1/2" x 7' 6 11/16"
temporary joist support

141a 4 3/16" x 1 1/2" x 5' 11 3/16"

141b 4 3/16" x 1 1/2" x 4' 3"

door cover rafter ledger

Clamp legs to 141ab to hold up in place
while installing 4.5" flatHead screws.

Mark overhang rafters on ledger front
then drill pilot holes from front to back
before installing screws from back to front.

-142(9) 3 1/2" x 2' 2 3/8" x 2' 5/8" diagonal
door cover rafter